

Teletek

The following information was sourced from: <http://www.freepbx.org/comment/281712#comment-281712>

Trunk Name  :


PEER Details

```
host=sipX.teletek.se  
username=[hexadecimal id].teletek.se  
secret=[password]  
type=peer  
insecure=very  
disallow=all  
canreinvite=no  
canredirect=no  
allow=alaw&ulaw&gsm  
context=from-pstn
```

← sipX should be their provided server such as sip3.teletek.se

← Put in your hex ID and password

Incoming Settings

USER Context  :

← Phone number with country prefix

USER Details

```
secret=[password]  
type=user  
context=from-trunk
```

← Your password

Registration

Register String

← Replace 08nnnnnnnn with the number used above and secret with your password
